

Accelerating the future



EPIC Meeting on Wafer Level Optics

Dr. Ir. T.A.H.M. Scholten

Friday, November 8, 2019

Customized High Volume Testers for Wafer Level Optics



Outline

- Introduction NTS-group
- Introduction NTS Optel
- DOE and MLA test parameters
- Configuration of an optical wafer tester
- Some challenging topics:
 - Pattern imaging (optics)
 - Laser module: Single versus multimode
Working distance & beam quality

NTS: First-tier systems supplier of (opto) mechatronic systems and mechanical modules



- Build-to-print and build-to-spec
- High complexity products
- Low volume manufacturing
- High mix of product diversity

Eindhoven

Headquartered in Eindhoven,
the Netherlands

€ 270+

Million turnover

1700+


Employees worldwide

70+

Years of experience in
manufacturing industry

NTS' global presence

- Development & Engineering,
- Precision Components,
- Precision Frames & Cabinets,
- System Integration




NTS Optel: Development and manufacturing of custom opto-mechanical systems



- Ray-tracing and opto-mechanics – ensuring best optical performance
- Optical tooling – enabling industrialization of your metrology solution
- Opto-mechatronic systems – custom, integrated turn-key inspection solutions
- Extensive team of highly qualified and experienced design and assembly engineers
- Design and build turn-key, one-off systems and prototypes
- In-house small and medium series production
- ISO 9001 and ISO 13485 certified



New facility April 2020



NTS Optel competences

We use ray tracing for our optical designs

And apply all imaginable optical techniques:

- Vision techniques
- Laser triangulation, distance and 3D-measurement
- Laser and white light interferometry
- Laser diffraction
- Spectroscopy

from EUV, UV, visible, NIR to IR.










Add the electronics:

- Analog and digital electronics design
- Embedded software



We design and build the mechanics

And implement software for processing, control and GUI


Thus, we provide complete solutions!



Some optical devices and systems





UV beam homogenizer



Endo-illuminator

Diverse products




Customized (high volume) testers for optical wafers



Accelerating the future

DOE/MLA spot generators

Beam shapers/homogenizers




Accelerating the future

Typical test parameters

- Relative zero order power
- Occurrence of hot-spots
- Total diffraction efficiency
- Horizontal and vertical diffraction or refraction angles (FOV)
- Relative spot or line powers
- Pattern contrast
- Spot and line quality in terms of FWHM
- Homogeneity over spot profile or diffuser profile
- Low and high frequency inhomogeneity of diffuser
- Whatever other parameters customers would like to test....

Basic optical wafer tester layout



Technical challenges

Pattern imaging optics:


- Cover a large FOV (up to 150°) with sufficient resolution
- Low sensitivity drop-off and distortion over the FOV
- Tolerant in wafer surface location
- Sufficient working distance

Laser module:


- Accurate center wavelength
- Stable operation
- Spot size fitting the active area
- High beam quality

Optical wafer tester:


direct imaging (conoscope) and **rear projection** imaging



Example manual load optical wafer tester




Optical wafer tester: front projection imaging




Comparison pattern imaging optics



Irradiance drop for projection on flat screen



Irradiance drop for projection using f- θ optics




Laser module design

Customer requirements:



- Wavelength (630/850/940nm)
- Single mode (/multi mode)
- Beam: Collimated/focused/VCSEL mimic
- Profile: top-hat / (truncated) Gaussian
- Spot size: illuminate active area
- Polarization state

Our additional requirements:



- Working distance (for chuck clearance)
- Beam quality at wafer
- Stable operation
- Laser safety
- Controllable
- Modular and flexible



Laser RF modulation




Laser spot quality and power confinement at wafer



Simple calculation:

- Typically 10mW laser power at DUT
- Diffracted in 10k beams \rightarrow $<1\mu\text{W}$ per spot
- Scattering passing the active area ends up in ZO position
- This should be $< 0.01\%$ to remain below the $1\mu\text{W}$


Laser working distance and spot quality



Last section of the laser module:


- Aperture:
 - to truncate the laser beam
 - to illuminate only the active area of the DUT
- 4F relay optics:
 - to image the aperture at the wafer level
 - to create sufficient space for the wafer chuck to move in between (50-100mm)
 - To control and confine any unwanted scattering

Laser beam to mimic VCSEL profile




The collimated configuration is generally used to test spot / line generators

To test the device with beam angles simulating a VCSEL, a diffuser is added in front of the aperture.




Tester calibration with build-in tool




Calibration 'tray' enabling:


1. Sensitivity calibration with wide angle IR-LED
2. Distortion calibration with rotating grating
3. Accurate reference power measurement



Sensitivity calibration



Distortion calibration



Many more challenges for next-time meeting:



Wafer handling, gripping and clamping

- manually/EFEM,
- Use of vacuum or mechanical solutions

Bow/warp of wafer (up to 1-2 millimeters!):

- Requiring bow/warp mapping
- Tip-tilt and height corrections with

Pitch variations over wafer:

- Alignment on multiple fiducials
- Use actual elements.

Sensitivity drift of pattern imaging camera: $\sim 0.5\%/ \text{degr.}$ @ 940nm.

- Thermal control
- Regular reference measurements

Calibration:

- Distortion,
- Sensitivity over VOF
- Laser power level (100% level)

Tester to tester variations: tester matching

UPH: Optimize camera resolution, alignment using fiducials, camera sync, multi-threading,

Serviceability: Modularity and simple first line service.

Thank you

Accelerating the future



Design choices / customization tasks

Chuck: 120mm CD type, 200mm round glass, 150mm round, 150mm square,
Embossed foil, Single and stacked wafers

Laser module design (wavelength, SM/MM, simulating divergent source, spot size,
power distribution). Laser focus position

Pattern imaging technique:

- Direct imaging (conoscope): Compact,

- Front or rear projection: laser speckle reduction required, flexible in FoV, simple optics, easy configurable, thickness of rear-projection foil: broadening.

- f-theta optics: multi spot or line angle measurements, spot quality.

- Camera type and resolution.

EFEM: cassette, spindles, foup.

Frame

GUI, wafer map, recipe structure, pareto, SPC,

This presentation was presented at EPIC Meeting on Wafer Level Optics 2019

HOSTED BY



DINNER SPONSOR



GOLD SPONSOR



SILVER SPONSORS



BRONZE SPONSORS



EU initiatives funded by
www.photonics21.org



PHOTONICS²¹
PHOTONICS PUBLIC PRIVATE PARTNERSHIP

