



HIGH PERFORMANCE FUNCTIONAL ADHESIVES
TO STIMULATE PHOTONICS INDUSTRY
TOMMY ZHANG DELO




HOW ADHESIVES ENABLE INNOVATION




FAMILY-OWNED € 205 M. REVENUES 1,000 EMPLOYEES



Adhesives / **Polymers**



Equipment




Curing Equipment














Some adhesive key functions



Reliable bonding

Of various materials and components



Precise & fast alignment

Of sensitive optical components



Thermal / electrical conductivity

For heat dissipation / electrical connections



Acoustic damping

To improve the sound quality



Optical functionality

Optically clear / adjustable RI / tailored transmission



Lightweight

Lighter than glass or metal



Enable mass production


Fast and reproducible processability for high UPH





CURING MECHANISMS

DUAL CURING FOR HIGHER PRODUCTION RATE










Compact camera module - bonding challenges






- 1 Active alignment
 - fast preliminary UV fixation for highprecision placement of housing
- 2 Lens barrel attach
 - adjusted flowability
 - good bonding strength to PC/LCP
- 3 Retainer ring replacement
 - black dual-curing adhesives
 - fast UV / light fixation
- 4 Bracket bonding
 - heat-curing adhesives
 - very good flow properties

Adhesive / polymer

Active alignment process









Adhesive technical properties


- High UPH due to UV fixation
 - > << 1 s with DELOLUX 503</p>
- Very low shrinkage for high optical stability
- Low temperature curing
 - » typically +80 °C, +60 °C also possible
- Excellent adhesion to plastic substrates
- Passes all reliability tests, for example
 - » +85 °C / 85 % r.h. > 500 h
 - » Drop test, tumble test
 - » Temperature cycling





Bonding challenges for Periscope Cameras





- Prism Attach: Low stress glass prism attach. Also optimized for bonding on black masking or coating
 - Prism side fill / reinforcement:
- Reinforcing the Prism for good drop test resistance with good flowability

 Prism Holder attach:

 Low viscous filling or high viscous attach



Prism Attach



Technical properties


- Dual curing adhesive needed for fixation of prism in perfect optical position
- Low shrinkage for high optical stability
- Moderate modulus to prevent stress on prism
- excellent adhesion to prism and/or coatings on prism
- Medium to high viscosity to avoid flowing away
- Low-temperature curing at temperatures starting from +60 °C to avoid damage of optical components and coatings
- Low outgassing

DELO's light- and heat-curing adhesive

UV light fixation in less than 0.5 s

Fast heat curing at +60 °C

DELO DUALBOND LT series




DELO

Active alignment process with DELO DUALBOND








2 Alignment



3 Light fixation



4 Curing








Prism Attach







Bonding to glass or black mask?

What material is black mask?

2023-09-07

How Adhesives enable Innovation



Side Fill

DELO

Technical properties


- Multiple Options: Purely heat curing or dual curing adhesive for prefixation
- Low modulus for high optical stability
- excellent adhesion to prism and/or coatings on prism and holder (LCP/PC)
- Low viscosity to fill small gap (down to 50μm)
- Jetability of adhesive for fast dispensing
- Low-temperature curing at temperatures starting from +60 °C to avoid damage of optical components and coatings
- Low outgassing

DELO's light- and heat-curing adhesive

UV light fixation in less than 0.5 s

Fast heat curing at +60 °C

DELO DUALBOND LT, SJ series




DELO


Active alignment process with DELO DUALBOND








Dispensing via
Jetter



Flow of adhesive within seconds













How Adhesives enable Innovation





Replication of optical elements (lens, DOE) from a UV-curing optical polymer

Nanoimprint Lithography (NIL)







Nanoimprint Lithography (NIL)



Replication of optical elements (lens, DOE) from a UV-curing optical polymer







Adhesive / polymer


Substrate (glass)


Stamp

How Adhesives enable Innovation 2023-09-07

Material solutions for wafer-level micro-optics










Lens Structures



Encapsulation

Optical solutions






Diffuser Material



Filter Material



Process solutions











Adjusting Refractive Index











Nanoimprint Lithography (NIL)







Benefits of wafer-level packaging with polymers

- All liquid process
- Maximum design freedom
- Minimum package size
- Maximize UPH
- Optimized mechanical stability
- Reflow stable package



Ambient light sensing



ToF sensing



3D sensing



Nanoimprint of grating structures


Polymer-based diffractive optical elements

- Surface relief gratings (SRG) imprinted on glass waveguide
- High refractive index of polymer
- Allows arbitrary grating structures*
 - » slanted, blazed, binary, analog
 - » Modulation of depth, slant, duty cycle
- Mass-producible on the wafer- or panel-scale via UV Nanoimprint Lithography (UV-NIL)





Combines high quality glass substrate with easy and fast processability of polymer Currently dominant waveguide technology



^{*}depending on master template





Adhesives enable ARVR

- Adhesives can do more than just bond parts together!
- Smart usage of adhesives enables completely new designs and processes
- Involve adhesive experts early in your project to benefit from their know-how
- Be smart don't underestimate the importance of proper adhesive selection!

We are looking for...

- New process ideas and partners to transfer those into mass production
- Raw materials to extend our current product portfolio
- Innovative companies who want to push boundaries for high-tech adhesives

- DELO with engineering lab
- DELO office
- DELO covered countries

DELO Industrial Adhesives DELO-Allee 1 · 86949 Windach Germany www.DELO.de

