



**LED light sources as  
narrow or  
broadband emitter  
in medical devices**

## Agenda

- Key facts about our company and products
- Non-invasive oxygen monitoring of premature children
- Chip selection by wavelength and spectrum
- Non-invasive hemoglobin measurement with LEDs
- Broadband emitters for multispectral imaging and diagnostic support

# Key Facts about our company

## Industrial leader in the field of LED technology

- Location Berlin Germany
- Cleanrooms
- 80 Employees

focused on  
the specific requirements  
of our customers




## Chip production



## SMD production



## LED-CHIPS



## SMD-LEDs




## Chip on Board - CoB



## UV-LEDs



## High Power SWIR-LEDs



## TO-LEDs



- Hermetically sealed TO-Packages with flat window or lens cap
- UVC & UVB wavelength  
230 nm | 265 nm | 275 nm | 308 nm  
325 nm | 340nm


- Size 6.0 (L) x 4.6 (W) x 4.3 (H) mm
- Circuit substrat: AlN Ceramics
- Lens with 20° viewing angle
- up to 400 mW output power
- Wavelength 980 nm- 2300 nm

- High-power, high-speed infrared LED
- Hermetically sealed TO-46 package
- Mounted on reflector header for beamforming
- Operating temperature -40° - +120°C

# LED applications in the medical field



**Disinfection of  
air, fluids and surfaces  
UV LEDs**



**Therapy  
UV, Red and IR LEDs**




**Ophthalmology  
Blue, Red and IR LEDs**




**Drug discovery  
Fluorescence  
UV & Blue LEDs**

**In this presentation the focus is on:**



**Vital signs sensing  
Multi-LED Modules**




**Hyperspectral Imaging  
Broadband LEDs**

# Non-invasive oxygen monitoring of premature children




Absorption and Reflection




Miniaturized flexible sensor based on LED-Chips and Photodiode-Chip

A lack of oxygen has a negative effect and leads to the death of brain cells, while an overdose acts like a cell poison and can lead to blindness in patients.









5.5 x 2.4 mm x 1.4mm



## Clear definition of the specific wavelength and spectral behaviour of the chips

- 10 different wavelength  
550 nm – 1300 nm
- Low forward current  
10 – 100 mA
- Output power  
2 – 10mW
- Harmless light (NIRS)  
to determine absolute  
haemoglobin oxygen
- Glue-free fixation
- Very soft silicone hull
- Reusable





## Advantages:

- Strong and stable optical signal
- Painless screening
- Easy and safe to use
- Environmentally friendly
- Cost effective


8 different LED-Chips (600 nm – 950 nm)  
VIS – NIR  
Selection of peak wavelength to +/- 3 nm  
wire-bonded and encapsulated with  
optical epoxy

Dimension within less than  $\varnothing$  4 mm

Every chip separat adressable



- Penetration depth depends on the wavelength
- The determination of Hemoglobin concentration is based on the light absorbance and reflectance characteristics of the skin.
- The amount of absorbance is related to the concentration and can be calculated.
- Small compact sensor with high signal-to-noise ratio for reliable measurement
- Temperature stability by heating up the LED module up to a certain constant temperature level








Vital signs sensing  
Multi-LED Modules

## LED Module with Multiple LEDs




Hyperspectral Imaging  
Broadband LEDs

## Single Broadband LED




**Hyperspectral imaging** is the intensity of reflected light for each pixel of an image. Each pixel contains detailed **spectral information**, allowing for the identification and analysis of objects Data Cube.

LED illumination supports camera systems for wound medicine




Hyperspectral imaging for minimally invasive procedures



The HSI cubes in the wavelength range from 500 to 1000 nm with SMD **OCL-480-GIR**.

This visual and near-infrared wavelength range contains various chemical information of the tissue.



- Oxygen saturation in superficial tissue layers
- Perfusion in deeper tissue layers
- Hemoglobin content
- Water content
- Fat content





**Advantages:**


- High Power SMD LED
- Single emitter
- Small footprint
- Dimension:  
6 mm x 4.6 mm x 1.1mm
- Temperature stability

**Temp (°C) Vs Current (mA) Plots of the SMD-LEDs**



**Temp (°C) Vs Spectrum (nm) Plots of the SMD-LEDs**





THANK YOU FOR YOUR ATTENTION!

**Antje Thamm**

**VP Sales & Marketing**



+49 (0)30 6576 3764



[a.thamm@epigap-osa.de](mailto:a.thamm@epigap-osa.de)